


HSV Cabling - Truss 8 lanes




HSV Cabling - Truss 10 lanes




HSV Cabling - Truss 8 lanes - Fiber



HSV Cabling - Truss 10 lanes - Fiber





Cabling that need to be mounted before HSV installtion (not included):

All cabling marked with red color are not included and need to be mounted and ready before HSV installation, this includes:

- 1. Fiber cables and patch panels between Timekeeping room and Catwalk racks
- 2. Rack cabinets at catwalk positions
- 3. CAT6 cables between Timekeeping Room and Cameras and/or between Rack Cabinets and Cameras
- 4. Power to the Catwalk Racks

Other requirements:

CAT 6 Cables must be of patch type quality and NOT installation wires with solid wire cores.

In the rack, cables are mounted on patch panel and on the truss, cables are mounted to wall outlets with 2connectors at each camera position

Fiber cables (2 pairs of Single Link) with SC connectors between rack and timekeeping room.

Power Outlet in Timekeeping Room

Desktop Space for Monitor and Keyboard for HSV operator.

Close to position of the mobile HSV rack.

Start Out Connector from quantum

Possibly mounted on a fixed electronic box close to mobile HSV position. 4pol Eco Mate connector.